

CMKF04-3126-YP8-AC


2003-2009 Ford Truck 650 CAT 3126, W-WO/AC

INSTALLATION NOTES

- 1. Disconnect negative battery cable. Remove innercooler tube and both rubber elbows. Remove Alternator bolts one at a time and replace them with allthread (3) and nuts (4). Torque to 35 ft. lbs.. Install spacer (2) onto each of the alternator studs. Install the pump bracket (1) with nuts (4) and lockwashers (5). Move O.E.M. idler from location "A" to location "B".
- 2. Install pump with bolts (11), lockwashers (12), and nuts (13). Align clutch pulley with the drive pulley and tighten bolts. Install idler (7) with spacer (6) and bolt (9), onto bracket (1) in location "E", with bolt (8) and flatwasher (7). Install belt (26) as shown in belt diagram. Install new innercooler tube (21) with new elbows (22, 23) and clamps (24, 25). Reconnect battery cable.

CMKF04-3126-YP8-AC

2003-2009 Ford Truck 650 CAT 3126, W-WO/AC



PARTSLIST

- 1. FMB 931 (1)
- 2. FMB 932 (4)
- 3. 10mm Allthread (4)
- 4. 10mm Nut (8)
- 5. 10mm LW (4)
- 6. FMB 935 (1)
- 7. 89016(1)
- 8. NOT USED
- 9. 10mm x 40mm Flanged bolt(1)
- 10. Clutch Pump Assembly (Sold Separately)
- 11. 3/8 x 1-1/2 NC (2)
- 12.3/8 LW (2)
- 13. 3/8 Nut NC (2)
- 14. MCA01 Clutch Mtg Plate (1)

- 15. 1/4 x 3/4 NC FHSCS (4)
- 16. Coil (Sold Separately)
- 17. Capscrew-19T34530 (3)
 - (t=8-10 ft/lbs)
- 18. Clutch (Sold Separately)
- 19. Flat Washer-21MZ3487(1)
- 20. Capscrew-19T38756 (1)
 - (t=20 ft/lbs)
- 21. 3-55-ST 3" Steel Elbow (1)
- 22. 3 1/2" Rubber Elbow (1)
- 23.3" Rubber Elbow (1)
- 24. 3-1/2" Hose Clamp (2)
- 25. 3" Hose Clamp (2)
- 26. Belt; 5081000 Dayco