

# A20/A30 PTO Capscrew Installation

The (2) dowel pins are installed in the 2 positions shown. The (8) 33 mm capscrews and (8) flat washers are used on the 8 mounting positions shown. Use (8) hardened flat washers under all capscrews and torque to 45 ft.lb.

