



ASC2 SERIES PTO CONTROL

INSTALLATION INSTRUCTIONS AND PARTS LIST


SUPPLEMENT KIT NO. 48T39261

NOTE: Both kits are for use with PTOs that normally use a rocker switch for activation. Use this instruction sheet in conjunction with PTO and Dump Pump installation instructions. Both kits allow air valve to activate the PTO through a pressure switch.

FOR USE WITH CS6/8 PTO

ITEM	QTY.	PART	DESC.
1	*	35T40821****	Air Valve Assembly
2	1	44MB6842PTC	Tube Fitting
3	*	45M44430	Air Tubing
4	1	44T35791	Coupler
5	1	31M14732	Pressure Switch
6	2	34T36641	Fork Terminal
7	*	33T36299	Fuse Assembly

* Included with PTO or Air Console Kit



FOR USE WITH CS20/21, CS24/25 OR THE CS10/11 PTOs

ITEM	QTY.	PART	DESC.
1	*	35T40821****	Air Valve Assembly
2	1	44MB6842PTC	Tube Fitting
3	*	45M44430	Air Tubing
4	1	44T35791	Coupler
5	1	31M14732	Pressure Switch
6	2	34T36641	Fork Terminal
7	*	33T36299	Fuse Assembly

* Included with PTO or Air Console Kit

