

GROUNDING BUSS PIN ASSIGNMENTS

PIN #	CONNECTOR 1	CONNECTOR 2
1	SECONDARY HARNESS	RELAY
2	SECONDARY HARNESS	FILTER BYPASS SWITCH
3	PRIMARY HARNESS	PTO KICKOUT CABLE
4	PRIMARY HARNESS	NOT USED
5	NOT USED	NOT USED
6	NOT USED	NOT USED
7	ANTI-ICE	NOT USED
8	ANTI-ICE	NOT USED
9	NOT USED	NOT USED
10	NOT USED	NOT USED
11	NOT USED	PUMP PRESSURE
12	NOT USED	CONTROL PANEL



Drwn by: BS Chkd by: RS 4/1/19 File: R3808

GROUNDING BUSS PIN ASSIGNMENTS

PIN #	CONNECTOR 1	CONNECTOR 2
1	SECONDARY HARNESS	RELAY
2	SECONDARY HARNESS	FILTER BYPASS SWITCH
3	PRIMARY HARNESS	PTO KICKOUT CABLE
4	PRIMARY HARNESS	NOT USED
5	NOT USED	NOT USED
6	NOT USED	NOT USED
7	ANTI-ICE	NOT USED
8	ANTI-ICE	NOT USED
9	NOT USED	NOT USED
10	NOT USED	NOT USED
11	NOT USED	PUMP PRESSURE
12	NOT USED	CONTROL PANEL



Drwn by: BS Chkd by: RS 4/1/19 File: R3808