




# MCA GK01 INSTALLATION INSTRUCTIONS



\* Best pull direction will vary depending on the application, kit design and pump location.



**Muncie<sup>®</sup>  
Power  
Products**

**Muncie Power Products, Inc.** Member of the Interpump Hydraulics Group  
General Offices and Distribution Center • P.O. Box 548 • Muncie, IN 47308-0548  
(765) 284-7721 • FAX (765) 284-6991 • E-mail [info@munciepower.com](mailto:info@munciepower.com)  
Web site <http://www.munciepower.com>