G.M. TRANSMISSION

RIGHT SIDE ONLY

(LEFT SIDE TURN PAGE) SAE 6-BOLT OPENING

MUNCIE


CAUTION: MAXIMUM OUTPUT SHAFT SPEED NOT TO EXCEED 2500 RPM.

NEW VENTURE NV-4500HD 2001-2006 3500 CAB CHASSIS

PTO DRIVE GEAR DATA:

(Gas engine applications are limited to the PF series hydraulic pump only due to catalytic converter interference.)
Footnotes: 4, 5

30T 7.94P 22.5° PA 30° R.H. **LOCATION:** Front **PLMF:** 1.114 **PLV:** 660 FPM **RPM:** 578



6-BO	_	FOOT	SHAFT		IGINE	-	ADAPTER	SPACER	CTIID KIT SI III I		INTERMITTENT RATING @ 1000 RPM of PTO	
TYP	E MODEL NUMBER	NOTES	ROTATION	HI	LO	REV	712711 1 211	0.7.0=	0102141	TYPE	TORQUE	HP
SINGL GEAR												
SINGL SPEEL MULTI GEAR	TG6S-G7913-C1TH	1, 2, 3 1, 2, 3 1, 2, 3 1, 2, 3 1, 2, 3 1, 2, 3 1, 2, 3	Opp Opp Opp Opp Opp Opp Opp	45 55 57 70 83 90 107					Included Included Included Included Included Included Included	Cable Cable Cable Cable Cable Cable Cable Cable	230 230 205 210 210 195 175	44 44 39 40 40 37 33
SH SERIE	S											
CLUT(SHIFT	СН											
1 FWD 1 REV												
AD/	PTER TO CHANGE ROTATION	Not availa	able									

8-BOLT	PTO	FOOT	SHAFT ENGINE %			%	ADAPTER	SPACER	STUD KIT	311111	INTERMITTENT RATING @ 1000 RPM of PTO	
TYPE	MODEL NUMBER	NOTES	ROTATION	HI	HI LO REV		ADAI ILII	OI AOLII	OTOD KIT	TYPE	TORQUE	HP
SINGLE SPEED MULTI GEAR												
1 FWD 1 REV												



FOOTNOTES:

- 1 TG Series Input Gear use #03T37766A Refer to kit program on page 10 & 11.
- 2 Only direct mount pump "T" hydraulic option and PF1 series pump can be used due to exhaust interference.
- 3 Lectra Shift requires heat shield not supplied. Solenoid interferes with oil fill plug but solenoid can be removed for oil level check.
- 4 Caution: This transmission requires a special oil available only from the dealer. GM PN12346190, 12346191.
- 5 When removing the aperture cover, check for a magnet on the inside. If present, mount this cover to the other side of transmission.

CAUTION: MAXIMUM OUTPUT SHAFT SPEED NOT TO EXCEED 2500 RPM.

G.M. TRANSMISSION

LEFT SIDE ONLY

(RIGHT SIDE TURN PAGE)





PTO DRIVE GEAR DATA:

LOCATION:



									PLV:	RPM:			
6-BOLT TYPE	P7 MODEL I	TO NUMBER	FOOT NOTES	SHAFT ROTATION	HI	IGINE LO	% REV	ADAPTER	SPACER	STUD KIT	SHIFT TYPE	INTERMITTENT 1000 RPM TORQUE	
SINGLE GEAR													
SINGLE SPEED MULTI GEAR	L	-IMI	ΓED	PTC) C	PI	EN	ING –	- SEE O	THEF	R SI	DE	
SH SERIES													
CLUTCH SHIFT													
1 FWD 1 REV													
ADAPTE	R TO CHANGE	ROTATION								Refer to Adapte	er Gear Asse	emblies in inc	dex.

8-BOLT	PTO	FOOT	SHAFT		IGINE	%	ADAPTER	SPACER	STUD KIT	Si iii i	INTERMITTENT RATING @ 1000 RPM of PTO	
TYPE	MODEL NUMBER	NOTES	ROTATION	н	LO	REV	ADAI ILII	OI AGEN	OTOD INT	TYPE	TORQUE	HP
SINGLE SPEED MULTI GEAR												
1 FWD 1 REV												

	─ PTO SEF	RIES & HOUSING DESIGNATOR	ASSEMBLY ARRANGEMENT (See Page 16 & 17)					
BREAK		┌ GEAR PITCH	OUTPUT SHAFT (See Page 7)					
OOWN		☐ INTERNAL RATIO	SPECIAL OPTIONS (See Page 7)					
		SHIFT OPTIONS (see page 7)						
EX: TG	6S - U	68 07 - C 1 B X						
EA. I G	03 - 0		PORTANT: FOOTNOTES MAY AFFECT PTO SELECTION					

FOOTNOTES:	