Low Speed High Torque Motors

MB Series - Seal Kit Instructions

Torque to
20-30 ft. lb.

1. Dust Seal
2. Housing
3. Shaft Seal
4. Thrust Washer
5. Thrust Bearings (2)
6. Shaft key
7. Shaft
8. Body Seals
9. Drive Link
10. Wear Plate
11. Rotor Assembly
12. Drive Link Spacer
13. Endcover
14. Endcover Plug
15. Assembly Bolt Washers (7)
16. Assembly Bolts (7)



FIGURE 1



FIGURE 2

Muncie® Power Products
Member of the Interpump Group

201 East Jackson Street • Muncie, Indiana 47305
800-367-7867 • Fax 765-284-6991 • info@munciepower.com • www.munciepower.com

Specifications are subject to change without notice. Visit www.munciepower.com for warranties and literature. All rights reserved. © Muncie Power Products, Inc. (2015)

IN15-04 (Rev. 10-15)