




FR67 PTO PRESSURE SWITCH

RELOCATION INSTRUCTIONS FOR FORD WITH GAS ENGINE

1. Using tubing kit, install elbow (A) into PTO gage port.
2. The short tubing (B) with reverse flared fittings is installed into this elbow using the short threaded end.
3. On the long threaded end attach the coupler (C) making sure the hex portion is attached to the tubing.
4. Attach the pressure switch (D) to the coupler.
5. Gently work tubing into a bend toward the closed PTO cover as shown.
6. Using clamp and socket capscrew (E) attach tubing to PTO cover.



**Muncie[®]
Power
Products**

IN10-03 Printed in the U.S.A.
© Muncie Power Products, Inc. 2010

Muncie Power Products, Inc. Member of the Interpump Hydraulics Group
General Offices and Distribution Center • P.O. Box 548 • Muncie, IN 47308-0548
(765) 284-7721 • FAX (765) 284-6991 • E-mail info@munciepower.com
Web site <http://www.munciepower.com>


Drive Products, Exclusive Agents for Canada, ISO Certified by an Accredited Registrar



FR67 PTO PRESSURE SWITCH

RELOCATION INSTRUCTIONS FOR FORD WITH GAS ENGINE

1. Using tubing kit, install elbow (A) into PTO gage port.
2. The short tubing (B) with reverse flared fittings is installed into this elbow using the short threaded end.
3. On the long threaded end attach the coupler (C) making sure the hex portion is attached to the tubing.
4. Attach the pressure switch (D) to the coupler.
5. Gently work tubing into a bend toward the closed PTO cover as shown.
6. Using clamp and socket capscrew (E) attach tubing to PTO cover.



**Muncie[®]
Power
Products**

IN10-03 Printed in the U.S.A.
© Muncie Power Products, Inc. 2010

Muncie Power Products, Inc. Member of the Interpump Hydraulics Group
General Offices and Distribution Center • P.O. Box 548 • Muncie, IN 47308-0548
(765) 284-7721 • FAX (765) 284-6991 • E-mail info@munciepower.com
Web site <http://www.munciepower.com>

Drive Products, Exclusive Agents for Canada, ISO Certified by an Accredited Registrar

